

1.



Enter Configuration

2.



Restore Factory Default Configuration

3.



Serial Port

4.



Baud rate 19200

5.



CR

6.



Exit Configuration