

Bluetooth Name Configuration

Please follow below instructions to configure the bluetooth name for each scanner.

1. Turn on the bluetooth after it's connected, click disconnect it, ignore the device or delete it. Then turn off the bluetooth on your phone or computer.
2. Scan the bluetooth name code (each scanner with one name code) then turn on the bluetooth on your phone or computer to search the new bluetooth name.

For example If you scan NT-1, you search the bluetooth name NT-1 and connect it.


If you scan NT-2, you search the bluetooth name NT-2 and connect it.

For configuring other bluetooth name please follow the same procedure

Make sure the old bluetooth name was disconnected, delete or ignore it otherwise it's hard to connect the new bluetooth name.



AT+NAME= NT-1




AT+NAME= NT-2




AT+NAME= NT-3



AT+NAME= NT-4



AT+NAME= NT-5



AT+NAME= NT-6



AT+NAME= NT-7



AT+NAME= NT-8